

# ACCULAB Montanel™ Progressive Lens Centration Chart




Printing Instructions for AccuLab Centration Charts (Print to Scale)

1. Go to **File > Print**
2. Select your printer
3. Under **Page Handling**, set **Page Scaling** to **None**
4. Click **OK** to print

**⚠ Important:**

Do **not** select "Fit to Printable Area."

Charts must be printed at **100% scale** to ensure accurate measurements.




[www.accumlab.net](http://www.accumlab.net)

Your Success Is Our Vision



# ACCULAB Montanel Progressive Lens Centration Chart



[www.accumlab.net](http://www.accumlab.net)

**Your Success Is Our Vision**

