



# UNDERSTANDING YOUR ORDER STATUS

Depending on the ordering portal you're using, your order status may appear slightly different than what's shown here. If you have any questions, feel free to reach out to AccuLab.

| Order Status                       | What It Means                                                                                                                              |
|------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|
| LENS ORDER                         | Your lens blank has been ordered                                                                                                           |
| LENS RECEIVED                      | Your lens blank has arrived to us                                                                                                          |
| LOG LENSES SF                      | Your lenses have been entered into our system (SF stands for 'semi-finished')                                                              |
| FTC RECEIVED                       | Your frame has arrived to us                                                                                                               |
| FRAME BIN REMOVED                  | Your order is on its way to the next department                                                                                            |
| BREAKAGE                           | Your lenses did not pass inspection and will be restarted                                                                                  |
| LT-980                             | <b>Tracer:</b> We are tracing your frame                                                                                                   |
| OTB80MANBLOCKER / OTB80 BLOCKER SU | <b>Blocker:</b> Your lenses are being blocked to begin the surfacing process                                                               |
| FLASH NG                           | <b>Generator:</b> The prescription is being cut into the lens                                                                              |
| ASP 80 POLISHER                    | <b>Polisher:</b> Your lenses are being polished                                                                                            |
| OTL 80 LASER                       | <b>Laser:</b> Laser marks are being etched into your lenses                                                                                |
| TINT COMPLETE                      | Your lenses have been tinted                                                                                                               |
| COATING / IN AR ROOM / AR COMPLETE | <b>Anti-Reflective Coating:</b> Beginning and ending                                                                                       |
| MEI EASY FIT / SANTINELLI          | <b>Edgers:</b> Your order is being edged                                                                                                   |
| MOUNTING                           | Your lenses are being mounted into the frame                                                                                               |
| FINAL INSPECTION                   | Last inspection before shipping                                                                                                            |
| INVOICED                           | Your order has been invoiced and is about to ship                                                                                          |
| SHIPPED                            | Your order has been shipped (Please note: Order status may say 'Shipped' when the order has only been invoiced and will ship the next day) |



## BLOCKER

Adhesive tape prevents scratches, while a heated alloy block secures the lens for grinding and polishing



## GENERATOR

A generator is a three-axis machine that uses a diamond tip to cut precise curves into lenses



## POLISHER

Lenses are polished in stages. Starting with an abrasive pad, then a smoother pad, and finished with a polishing compound



## LASER

AccuLab's laser system precisely etches key details, like lens style, axis, material, and add power, onto each lens



## AR COATING

Lenses receive a scratch coat, ultrasonic cleaning, and multi-layer AR coating for a smooth, dirt- and water-resistant finish



## EDGING

A tracer measures the frame, and an edger shapes and bevels the lenses to fit the frame, using water for cooling